



Manual Flowmaster USB Driver Install


1. Plug in TSI Flowmaster device to Computer USB
2. Open C:\Program Files (x86)\TSI Flowmeters\Flowmaster\Inf folder and run inf-wizard.exe
3. Select the item as shown




4. Press Next and leave the default settings



5. Save the drives to a directory such as C:\Temp or Downloads folder



6. Select the "Install Now" option



7. Accept any further messages to complete installation